

Thank you for purchasing Extreme Antenna Mod Kit for your Netgear router. We will show you how to install the antennas for your router.



Netgear WN2500RP Antenna Installation Instructions:

1. No soldering required
2. Open the unit. You can use a torque wrench T9.







Inside of the Netgear WNR3500L v.1

Before the modification.

3. Drill $\frac{1}{4}$ inch holes in the vents.



4. Attach the MS156 cables to the connectors, you must push straight down and hear a snapping sound.



14. After drilling there will be a little plastic left around the inside hole that will need removing. Just use a kitchen knife or other small knife to remove the plastic.

Be sure the nut on the RP-SMA plug is nice and tight, otherwise your antennas will flop.

When putting the case back together make sure the wires are secured in place (use clear tape for that) otherwise you can pinch them with screws!

Enjoy