

Alfa Tube 2H Configuration.

Once you have set you ip address to static please follow this:

Step 1: Log in to Alfa Tube2H setup page by entering 192.168.2.1 into your web browser.

Step 2: Input User/Pass – admin/admin

Step 3: Click on Easy Set Up

Step 4: Select 'Client Bridge' mode

Step 5: Click on Site Survey

Step 6: Select desired network (at this point you may want to adjust the antenna position and click Re-Scan to achieve best signal strength).

Step 7: If no password is needed click Done.

Step 8: change your computer IP back to dynamic.

Step 9: Try going on any web page.