

Rokland Tube2HP site survey issue

The screenshot shows the configuration interface for an ALFA Network 11n Wireless Router. The top navigation bar includes 'Status', 'Easy Setup', 'Advanced', and 'Language' (set to English). The 'Advanced' tab is selected, and the 'Advanced Wireless Settings' section is active. The 'Enable Long Distance' checkbox is highlighted with a red box.

Setting	Value
Wireless On/Off	Turn Off
AP MAC Address	00:C0:CA:96:97:6C
Packet Aggregate	Enable
WMM	Enable
TX Power	23 dBm
Beacon Interval	100 ms
DTIM	1
RTS/CTS	Bytes
Fragmentation Threshold	Bytes
Enable Long Distance	<input type="checkbox"/>
Station Control (SSID I)	127
Wireless Isolate	Disable
Thresholds, dbm	LED1:- 94 LED2:- 80 LED3:- 73 LED4:- 65

Need to Enable Long Distance

Where to Enable Long Distance: Advanced → Wireless Settings → Advanced